


# Pilot Operating handbook

And

# Flight training supplement



**AEROPRO**

# **EuroFOX**

Aircraft Model:

**EuroFOX 3K TOW**

Serial Number: **56219**

Registration: **4X - HSE**

Date of Issue: May 1. 2019

Stamp, Signature

**This aircraft was manufactured in accordance with Light Sport Aircraft airworthiness standards and does not conform to standard category airworthiness requirements.**

## DATA OF THE AEROPLANES

	Type	Country of Production	Serial Number:	Year of production
<b>Fuselage</b>	EuroFOX 3K TOW	AEROPRO	56219	2019
<b>Engine</b>	ROTAX 912 iS SPORT	BOMBARDIER- ROTAX GMBH AUSTRIA	7 704 724	2018
<b>PROPELLER</b>	DUC FC	DUC HELICES France	S/N: 160	2018

.....  
**Signature**

.....  
**Stamp**



TABLE OF CONTENTS:

0.1	INTRODUCTION .....	0-9
0.2	CERTIFICATION BASIS .....	0-9
0.3	MANUFACTURER .....	0-9
0.4	WARNING, CAUTION AND NOTE .....	0-9
<b>1.</b>	<b>AIRPLANE AND SYSTEMS DESCRIPTION.....</b>	<b>1-10</b>
1.1	ENGINE .....	1-11
1.2	PROPELLER .....	1-12
1.3	FUEL AND FUEL CAPACITY .....	1-12
1.4	OIL .....	1-13
1.5	OPERATING WEIGHTS AND LOADING (OCCUPANTS, BAGGAGE, FUEL, BALLAST) .....	1-14
1.6	COCKPIT OVERVIEW .....	1-15
1.7	OTHER EQUIPMENT .....	1-20
<b>2.</b>	<b>OPERATING LIMITATION.....</b>	<b>2-21</b>
2.1	STALL SPEED AT MAXIMUM TAKEOFF WEIGHT ( $V_S$ AND $V_{SO}$ ) .....	2-21
2.2	FLAPS EXTENDED SPEED RANGE ( $V_{SO}$ TO $V_{FE}$ ) .....	2-22
2.3	MAXIMUM MANEUVERING SPEED ( $V_A$ ) .....	2-22
2.4	NEVER EXCEED SPEED ( $V_{NE}$ ) .....	2-22
2.5	CROSSWIND AND WIND LIMITATION .....	2-22
2.6	SERVICE CEILING .....	2-23
2.7	LOAD FACTORS .....	2-23
2.8	PROHIBITED MANEUVERS .....	2-23
2.9	OTHER LIMITATIONS .....	2-23
<b>3.</b>	<b>WEIGHT AND BALANCE INFORMATION.....</b>	<b>3-25</b>
3.1	INSTALLED EQUIPMENT LIST .....	3-25
3.2	CENTER OF GRAVITY (CG) RANGE AND DETERMINATION .....	3-25
3.2.1	<i>Airplane weight and balance statement .....</i>	<i>3-26</i>
3.2.2	<i>Weight and balance determination for flight .....</i>	<i>3-26</i>
3.2.3	<i>Detailed calculation of CG position .....</i>	<i>3-27</i>
<b>4.</b>	<b>PERFORMANCE.....</b>	<b>4-29</b>
4.1	TAKEOFF AND LANDING DISTANCES .....	4-30
4.2	RATE OF CLIMB.....	4-30
4.3	CRUISE SPEEDS .....	4-30
4.4	RPM.....	4-31
4.5	FUEL CONSUMPTION .....	4-31

4.6	OTHER PERFORMANCE DATA .....	4-31
<b>5.</b>	<b>EMERGENCY PROCEDURES.....</b>	<b>5-32</b>
5.1	INTRODUCTION .....	5-32
5.2	ENGINE FAILURE AND EMERGENCY LANDINGS .....	5-32
5.2.1	<i>Engine Failure during Take-Off Run.....</i>	<i>5-32</i>
5.2.2	<i>Engine Failure during Take-Off.....</i>	<i>5-32</i>
5.2.3	<i>In-flight Engine Failure.....</i>	<i>5-33</i>
5.2.4	<i>Additional information to engine failure and emergency landing procedures .....</i>	<i>5-33</i>
5.3	IN-FLIGHT ENGINE STARTING .....	5-34
5.4	FIRE.....	5-34
5.4.1	<i>Engine fire on the ground.....</i>	<i>5-35</i>
5.4.2	<i>Engine fire during takeoff.....</i>	<i>5-35</i>
5.4.3	<i>Engine fire in flight.....</i>	<i>5-36</i>
5.4.4	<i>Cockpit or electrical fire.....</i>	<i>5-36</i>
5.5	GLIDING .....	5-37
5.6	PRECAUTIONARY LANDING .....	5-37
5.7	BLOWN-OUT TIRE LANDING .....	5-38
5.8	DAMAGED LANDING GEAR LANDING .....	5-38
5.9	VIBRATIONS OR OTHER ENGINE PROBLEM .....	5-38
5.10	INADVERTENT ICING ENCOUNTER .....	5-38
5.11	EXTREME TURBULENCE ENCOUNTER .....	5-39
5.12	ELECTRICAL SYSTEM MALFUNCTIONS .....	5-39
5.12.1	<i>Indicator of warning light is illuminated immediately - Switch ON Backup battery switch. All avionics and other equipment is powered from the battery, so the power source is limited. Try to switch off instruments not necessary for flight and land at the nearest airfield.....</i>	<i>5-39</i>
5.13	INADVERTENT STALL AND SPIN RECOVERY .....	5-39
5.13.1	<i>The following general procedure should be followed should a stall occur: .....</i>	<i>5-39</i>
5.13.2	<i>The following general procedure should be followed should a spin occurs: .....</i>	<i>5-39</i>
<b>6.</b>	<b>NORMAL PROCEDURES.....</b>	<b>6-40</b>
6.1	PRE-FLIGHT INSPECTION .....	6-40
6.2	DAILY INSPECTION .....	6-41
6.3	ENGINE STARTING .....	6-44
6.3.1	<i>Use of External Power Supply.....</i>	<i>6-44</i>
6.3.2	<i>Engine Starting.....</i>	<i>6-44</i>
6.3.3	<i>Warming up engine.....</i>	<i>6-46</i>

6.4	TAXIING .....	6-46
6.4.1	<i>Prior to Taxiing</i> .....	6-46
6.4.2	<i>Taxiing</i> .....	6-46
6.5	NORMAL TAKEOFF.....	6-46
6.5.1	<i>Prior to TakeOff</i> .....	6-47
6.5.2	<i>Take-Off</i> .....	6-47
6.6	BEST ANGLE OF CLIMB SPEED ( $V_X$ ).....	6-48
6.6.1	<i>Climbing</i> .....	6-48
6.7	BEST RATE OF CLIMB SPEED ( $V_Y$ ).....	6-49
6.7.1	<i>Climbing</i> .....	6-49
6.8	CRUISE .....	6-49
6.8.1	<i>Cruise Flight</i> .....	6-49
6.9	APPROACH.....	6-51
6.9.1	<i>Descent</i> .....	6-51
6.9.2	<i>Downwind</i> .....	6-51
6.10	NORMAL LANDING.....	6-51
6.10.1	<i>On Base Leg</i> .....	6-51
6.10.2	<i>On Final</i> .....	6-52
6.10.3	<i>Landing</i> .....	6-52
6.10.4	<i>After landing</i> .....	6-52
6.10.5	<i>Engine Stopping</i> .....	6-52
6.10.6	<i>Post-Flight Check</i> .....	6-53
6.11	SHORT FIELD TAKEOFF AND LANDING PROCEDURES .....	6-53
6.12	BALKED LANDING PROCEDURES .....	6-54
6.13	INFORMATION ON STALLS, SPINS AND ANY OTHER USEFUL PILOT INFORMATION.....	6-54
6.13.1	<i>Rain</i> .....	6-54
6.14	TOWING GLIDERS .....	6-55
6.14.1	<i>General</i> .....	6-55
6.14.2	<i>Flight limit</i> .....	6-55
6.14.3	<i>NORMAL PROCEDURES for towing gliders</i> .....	6-55
6.14.4	<i>Before Take Off</i> .....	6-55
6.14.5	<i>Take OFF roll</i> :.....	6-56
6.14.6	<i>Climbing</i> : .....	6-56
6.14.7	<i>Cruising speed according to limitations of towed glider</i> .....	6-57
6.14.8	<i>Before landing pilot has to go on low pass to drop the rope on the designate place</i> .....	6-57
<b>7.</b>	<b>AIRCRAFT GROUND HANDLING AND SERVICING.....</b>	<b>7-58</b>
7.1	SERVICING FUEL, OIL, COOLANT .....	7-58
7.1.1	<i>Servicing fuel</i> .....	7-58

7.1.2	<i>Servicing oil</i> .....	7-58
7.1.3	<i>Servicing coolant</i> .....	7-59
7.2	LANDING GEAR TIRE DIMENSION AND PRESSURE .....	7-59
7.3	TOWING AND TIE-DOWN INSTRUCTIONS .....	7-59
7.3.1	<i>Aircraft towing instruction</i> .....	7-59
7.3.2	<i>Aircraft tie-down instruction</i> .....	7-60
<b>8.</b>	<b>REQUIRED PLACARDS AND MARKINGS .....</b>	<b>8-61</b>
8.1	AIRSPED INDICATOR RANGE MARKINGS .....	8-61
8.2	OPERATING LIMITATION ON INSTRUMENT PANEL .....	8-62
8.3	PASSENGER WARNING .....	8-63
8.4	“NO INTENTIONAL SPINS” .....	8-63
8.5	MISCELLANEOUS PLACARDS AND MARKINGS .....	8-63
<b>9.</b>	<b>SUPPLEMENTARY INFORMATION.....</b>	<b>9-64</b>
9.1	FAMILIARIZATION FLIGHT PROCEDURES .....	9-64
9.2	PILOT OPERATING ADVISORIES .....	9-64
9.3	FURTHER INFORMATION .....	9-64



## 0. General information

### 0.1 Introduction

This handbook is provided with your aircraft to allow you to attain as much knowledge about the aircraft as its operation as possible. This manual is following ASTM F 2245–11 and ASTM 2746-14 document – Standard Specification for Design and Performance of a Light Sport Airplane. Read this manual thoroughly before your first flight and make sure you understand all the information contained here. This aircraft is equipped with non-certified engine that meets ASTM F-2339 engine standard. Flying this aircraft must always be done with the possibility of a safe landing due to loss of engine power. Pay attention to the fact that you as the pilot are fully responsible for safety of your passengers and persons or property on the ground.

### 0.2 Certification Basis

This aircraft was manufactured in category 95.55 airworthiness standards and with type certificate Micro light airworthiness by Slovak Aviation Authority issues with No.: V-82/2004 and V – 84/2007.

### 0.3 Manufacturer


AEROPRO s.r.o  
Dlhá 126  
949 07 Nitra  
Slovak Republic  
[www.aeropro.sk](http://www.aeropro.sk)

### 0.4 Warning, Caution and Note

In this handbook the following is used to highlight especially important information:

<b>WARNING</b>	<b>Information which could prevent personnel injury or loss of life</b>
<b>CAUTION</b>	<b>Information which could prevent damage to equipment</b>
<b>NOTE</b>	<b>Information of special importance to pilots</b>

## 1. Airplane and Systems Description



EuroFox is designed as a high-wing monoplane. A two-spar wing is equipped with flaperon. Fuselage is an open truss structure welded of steel tubes. Tail unit is formed of a lattice-work tube frame. The airplane is



Fuel pressure	- minimum .....	1.7 bar
	- maximum .....	4.0 bar
Consumption at starting .....		16.2 l/h
Consumption at 75% of power rating .....		12.1 l/h
Specific consumption .....		285 g/kWh
Propeller gearbox reduction ratio .....		2.43 : 1

For more details see **Operator's Manual for all versions of Rotax 912** supplied with the engine.

<b>WARNING</b>	<b>This aircraft is equipped with non-certified engine</b>
	<b>Flying this aircraft must always be done with the possibility of a safe landing due to loss of engine power. The pilot is fully responsible for consequences of such failure.</b>

## **1.2 Propeller**

The DUC FC propeller is made by DUC Helices – company. The propeller is a three-bladed, ground adjustable, clockwise rotation, tractor, made of composite. Propeller diameter – 1728 mm

For additional propeller information see **Operators Manual and Technical description** supplied with the propeller.

## **1.3 Fuel and fuel capacity**

Fuel tank capacity - wing tanks .....	2x 40 litres
- central connecting tank .....	6 litres
Max. fuel quantity .....	86 litres
Usable fuel quantity .....	85 litres
Unusable fuel quantity .....	1 litre

Fuel specification..... Premium unleaded auto fuel (Standard Spec. for Automotive Spark-Ignition Engine, Fuel, ASTM D 4814) or AVGAS 100 LL.

Due to the higher lead content in AVGAS, the wear of the valve seats, the deposits in combustion chamber and lead sediments in the lubrication system will increase. Therefore, use AVGAS only if you encounter problems with vapor lock or if other fuel types are not available.

For additional information concerning fuel specification consult **Operator's Manual for all versions of Rotax 912** supplied with the engine.

The fuel system includes two wing tanks of 40 litres each, a central tank of 6 litres, Fuel drain valve, fuel valves, a fuel filter, two fuel pumps and connecting lines.

The fuel is gravity-fed from the right-hand or left-hand wing tank into the central tank depending which wing tank fuel valve is open. The fuel is then further directed from the central tank via the main fuel valve and fuel filter into the serially connected two electrical fuel pumps which deliver the fuel to the engine injectors.

The amount of fuel in each tank is indicated by a visual fuel gauge which is a part of each tank. Minimum fuel quantity in the central tank is indicated by a warning light on the instrument panel. The remaining fuel (4,1 litres), is in that case enough for approximately 10 minutes of flight. The warning light condition can be verified any time by pushing the control button. No red light indication when the control button is pushed and held means the bulb is blown out and the minimum fuel quantity is not indicated:- In this case, make a more conservative estimate for fuel on board, check fuel quantity in wing tanks and land as soon as you are not confident of the fuel quantity inside the wing tanks.

Do not forget to properly manipulate the fuel tank valves to ensure continuous flow of fuel to the engine.

The fuel drain valve outlet is behind the left seat on the outside bottom side of the fuselage; to drain off water and dirt, the drain pipe is to be pressed into the fuselage and subsequently a fuel sample is to be taken.

For refuelling information see section [7.17.1](#)

## **1.4 Oil**

Oil tank capacity.....3.2 litres

Maximum oil quantity .....2.6 litres

Minimum oil quantity .....2.1 litres

Oil specification:

Use motorcycle oil of a registered brand with gear additive. Caution: When selecting the most suitable lubricants refer to the additional information in the Rotax Service Information SI-18-1997.

- Use only oil with API classification "**SF**" or "**SG**"!
- Due to the high stresses in the reduction gears, oils with gear additives such as high performance motor cycle oils are required

- Because of the incorporated friction clutch, oils with friction modifier additives are unsuitable as this could result in a slipping clutch during normal operation.
- Heavy duty 4-stroke motor cycle oils meet all the requirements. These oils are normally not mineral oils but semi- or full synthetic oils.
- Oils primarily for Diesel engines are **insufficient** due to **high temperature properties and additives which favor clutch slipping, generally therefore are unsuitable.**

CAUTION: If the engine is mainly run on AVGAS, **more frequent** oil changes will be required. See Rotax Service Information SI-18-1997.

For additional information concerning oil system consult **Operator's Manual for all versions of Rotax912** supplied with the engine.

The maximum and minimum oil level are indicated by two marks on the dip stick in the oil tank.

### **1.5 Operating weights and loading (occupants, baggage, fuel, ballast)**


Empty weight (standard version).....	289 kg
Max. take-off weight.....	560 kg
Max. landing weight .....	560 kg
Max. fuel weight.....	61 kg
Max. baggage weight in baggage compartment .....	20 kg
Maximum number of persons on board.....	2
Minimum crew weight .....	54 kg

<b>WARNING</b>	<b>Make sure that above mentioned weight limits are strictly followed.</b> <b>Structural failures which result from overloading of the aircraft may be dramatic and catastrophic.</b>
----------------	--

The additional stress placed on the structural parts by overloading can accelerate the occurrence of metal fatigue failures. Also flight characteristics might change significantly when aircraft is overloaded.

Takeoff and landing distance is significantly longer for overloaded aircraft. Overloading of the aircraft is one of the typical causes of accidents.

## 1.6 Cockpit overview



LAYOUT OF CONTROLS AND INSTRUMENTS

(see following pages for details )

1. Control stick	14. Warning light ignition	29. Map compartment	
2. Rudder pedals	15. Throttle control lever	30. Ventilation	
3. Wing flaps	16. Oil flap lever	31.1. Landing light	
4. Trim elevator	17. Cockpit heating	31.2. Strobe light	
5. Fuel cock	18. Lever for rope release	31.3. Position light	
6. Master Switch	19. ASI	31.4. Avionic	
7. The last 4 lit. war. light	20. EIS, EFIS	32.1. Landing light	10A
7. Min. fuel pushbutton	21. Slip indicator	32.2. Strobe light	3A
8.a Fuel pump (Main) + light	22. Altimeter	32.3. Position light	2A
8.b Fuel pump (Aux) + light	23. VSI	32.4. Avionic	5A
9. Start power switcher ( momentary )	24. FLARM	32.5. EIS /EFIS CB	5A
10. Backup battery switcher (guarded )	25. Compass		
11. Circuit breaker 30A	26. Radio		
12. Circuit breaker 30A	27. Transponder TRIG		
13. Ignition	28. Cigarette socket + 5A CB		

II. List of installed instruments and other equipment:

<b>Instrument</b>	<b>Type</b>	<b>Serial No.</b>
EIS – Kanardia	E-PFDEMS-K 3,5	
Magnetic compass	MC DS-2L	
GPS	N/A	
Radio	GARMIN GTR 200	
Transponder	TRIG TT21	-



Electronic Flight and Engine information System



More information according E-PFDEMS-K



Figure 1 - Airspeed Indicator marking




Figure 2 - Ignition and master switch




Figure 3 - Main Fuel Valve open and close position




Figure 5 – Central panel

Note: Rotate throttle lever for fine power settings (clockwise to increase power, counterclockwise to reduce power), for larger changes push/pull throttle when the button is pressed and held




Figure 6 – Flaps and trim



Figure 7 – Switches and fuses panel

Figure 8 – Control lights and fuel reserve bulb check button



Figure 9 – Door locking mechanism

The battery (SBS-8, 12 V, 7 Ah ) is located behind the right-hand pilot's seat. Nominal voltage in aircraft system is 13.5 to 14.2 V. The engine is equipped with integrated AC generator with external rectifier-regulator (12 V, 20A DC)

## 1.7 Other equipment

reserved

## 2. Operating limitation

Airspeed indicator system calibration:

km/h (Indicated Air speed)	km/h (Calibrated Air speed)
64	71
74	77
92	95
111	95
130	111
148	127
167	159
185	175
207	186
219	197
230	208

As requested by ASTM F-2245-04 §9.1 all flight speeds are presented as calibrated airspeeds in kilometre per hour (km/h). As the calibrated airspeed cannot be usually determined by simple reading of aircraft airspeed indicator, corresponding Indicated airspeed in kilometres per hours (km/h) are also presented in this document. All airspeed values in this handbook assume no instrument error.

### 2.1 Stall speed at maximum takeoff weight ( $V_s$ and $V_{SO}$ )

Aircraft configuration	Stall speed – angle of bank 0°	
	Km/h (Indicated Air speed)	Km/h (Calibrated Air speed)
Flaps down ( $V_{SO}$ )	65	72
Flaps up ( $V_s$ )	78	82

**WARNING**

The stall speeds mentioned above are with wings levelled. Once any angle of bank (e.g. turn) is encountered the stall speed is significantly increasing.

Example: angle of bank – 60° .....  $V_S = 120$  km/h

The more bank – the higher stall speed. This simple rule is especially important when a turn at maximum permitted angle of bank (60°) is performed. Do not start the turn until you have sufficient airspeed reserve – recommended entry speed is 150 km/h. Full throttle is also essential to have sufficient thrust reserve as the drag is increasing during a steep turn.

## 2.2 Flaps extended speed range ( $V_{SO}$ to $V_{FE}$ )

	km/h (Indicated Air speed)	km/h (Calibrated Air speed)
Lower limit	65	72
Upper limit	150	145

## 2.3 Maximum maneuvering speed ( $V_A$ )

	Km/h (Indicated Air speed)	Km/h (Calibrated Air speed)
Max. manoeuvring speed ( $V_A$ )	175	167

## 2.4 Never exceed speed ( $V_{NE}$ )

	Km/h (Indicated Air speed)	Km/h (Calibrated Air speed)
Never exceed speed ( $V_{NE}$ )	230	215

## 2.5 Crosswind and wind limitation

Maximum permitted wind speed components for take-off and landing:

Max. wind (in runway direction)..... 40 km/h (22 knots)

Crosswind.....28 km/h ( 15 knots)

tail wind..... 10 km/h (5 knots)

Cross wind takeoffs and landings require training and experience, the higher crosswind component, the better your skill must be. Do not fly without proper experience when the wind speed is approaching the limit.

Avoid takeoffs with tail wind when possible – the total takeoff distance is significantly longer and longer ground distance is required to gain altitude.

When landing with tail wind the aircrafts possessive ground speed is higher resulting in longer landing distance.

## **2.6 Service ceiling**

Ceiling.....14 760 ft

<b>WARNING</b>	<b>Oxygen mask and/or other equipment required to reach maximum ceiling, consult respective regulations.</b>
----------------	--

## **2.7 Load factors**

Flaps up:

Maximum positive Center of gravity load factor ..... + 4 Gs

Maximum negative Center of gravity load factor ..... - 2 Gs

Flaps down:

Maximum positive Center of gravity load factor ..... + 2 Gs

Maximum negative Center of gravity load factor .....0 Gs

## **2.8 Prohibited maneuvers**

<b>WARNING</b>	<b>Aerobatics, intentional stalls and spins are prohibited. Maximum angle of bank : 60°</b>
----------------	---

## **2.9 Other Limitations**

<b>WARNING</b>	<b>No smoking</b>
----------------	-------------------

<b>WARNING</b>	<b>Flights with rear canopy removed are prohibited</b>
----------------	--

**WARNING**

**Only VFR day flights at ambient temperature above -10° C are permitted.**

**Flights at ambient temperature between -10° C and 0° C are permitted only under no icing conditions.**

**WARNING**

**IFR flights and flying in clouds is prohibited.**

**Flight into know icing is prohibited**

This aircraft is not certified for operation in IMC (Instrument meteorological conditions). Always stay clear of clouds and have visual contact with the ground. Follow the airspace classification regarding distance from clouds. Always evaluate weather during your flight and try to get weather information from your destination using radio whenever possible. When weather is deteriorating make a diversion or turn back before the low cloud base and/or low visibility are critical.



### 3. Weight and Balance Information

#### 3.1 Installed equipment list

		VFR Day
Kanardia FIS and EFIS	Airspeed indicator	X
	Turn Bank indicator	X
	Attitude indicator	X
	Altimeter	X
	Magnetic compass	X
	Vertical speed indicator	X
	Oil Pressure indicator	X
	Oil temperature indicator	X
	Fuel pressure indicator	X
	Head temperature indicator	X
	Radio	X
Intercom	-	
Transponder	X	
ELT	-	
12V socket	X	

#### 3.2 Center of gravity (CG) range and determination

Aircraft handlings and performances have been determined for this range of CG positions.

	Front limit (%)	Rear limit (%)
Center of gravity limits	20	34

### 3.2.1 Airplane weight and balance statement

The CG position of empty aircraft is determined by weighting. The procedure is described in the Maintenance manual. The whole procedure must be repeated and new **Airplane weight and balance statement** must be prepared whenever a modification or repair having impact to the weight of the aircraft occurs.


Serial Number

**56219**

Registration:

**4X-HSE**

#### Aircraft Leveling:



#### Values Weighed:

Main wheels

right-hand  
left-hand

MRH =	<input type="text"/>
MLH =	<input type="text"/>
MTS =	<input type="text"/>

L =   
L<sub>1</sub> =

Nose wheel

Resulting weight

**Mres =**

#### C.G. position

$$B = (M_{pr} \times L) / M_{vys} = \quad \text{mm}$$

$$X = L_1 - B + 50 = \quad \text{mm}$$

$$\bar{X} = (X \times 100) / 1300 = \quad \% B_{SAT}$$

Date:

Performed by:

### 3.2.2 Weight and balance determination for flight

<b>WARNING</b>	<b>The aircraft must not be operated in violation of its approved weight and balance limitations to assure safe flying.</b>
----------------	---


Maximum takeoff weight is the maximum weight approved for the start of the takeoff roll.

The table given below represents the maximum amount of fuel for given crew weight and given weight in the baggage compartment. The CG (center of gravity) position is within the approved range for all combinations in the table and any interpolation between displayed values.

Max. Take-Off Weight									
Weight Baggage (kg)	Crew Weight (kg)								
	55	110	120	130	140	150	160	170	180
5 kg	85 L	85 L	85 L	85 L	85 L	85 L	85 L	85 L	82 L
10 kg	85 L	85 L	85 L	85 L	85 L	85 L	85 L	85 L	75 L
20 kg	85 L	85 L	85 L	85 L	85 L	85 L	85 L	75 L	61 L

### 3.2.3 Detailed calculation of CG position

As all items are located behind the leading edge of the wing, the leading edge was selected as the reference plane. The table below shows a typical calculation including an example.



Empty aircraft		Weight (kg)	X (mm)	Moment (kg.cm)
Crew			<b>440,0</b>	
		<i>Example:</i> 180		<i>Example:</i> 792
Fuel	Liters		<b>440,0</b>	
	<i>max 85 liters</i>	<i>Example:</i> 43		<i>Example:</i> 187,44
Baggage			<b>1200,0</b>	
		<i>Example:</i> 10		<i>Example:</i> 120
Total			X	
		<i>Example:</i> 487		<i>Example:</i> 1955,6
Loaded aircraft CG position in inches:		$X_T = \frac{\text{Total moment}}{\text{Total weight}} \frac{\boxed{1}}{\boxed{2}}$		
<b>Example</b>		$X_T = \frac{1956 \times 100}{487} = \mathbf{402 \text{ mm}}$		
Permitted C.G. range in inches	<b>259 mm ≤</b>	.....	<b>≤ 416 mm</b>	
Loaded aircraft CG position in % MAC:	$[\%] = \frac{X_T}{13} * 100$			
<b>Example [%]</b>	$\frac{402 \times 100}{1300} = 30,89 \%$			
Permitted C.G. range in %	<b>20% ≤</b>	.....	<b>≤ 34%</b>	

## **4. Performance**

The data is based on particular flight measurements undertaken with the aircraft of this type in good service conditions and with application of average piloting technique. The performance values stated below are calculated at sea level of the international standard atmosphere (ISA). Variations in pilot technique can cause significant differences as well as other conditions like runway slope, runway surface condition, humidity etc.

Use the following data for guidance but do not plan a takeoff or landing when only 50 ft excess runway is available or do not plan a cross country with only 2 gallons fuel planned when arriving to your destination. Always be conservative when planning a flight and be ready for the unexpected – not forecasted wind, atmospheric turbulence or sudden weather change in destination forcing you to divert to airfield 60 NM away. Always plan a reasonable fuel reserve – 30 to 60 minutes seems to be sufficient time for most of flights, but this time should be even more increased when complicated weather conditions (strong headwind or rain showers) are expected en route.

The propeller installed on your aircraft was set to achieve the best compromise between takeoff and cruising performance (the performance information below is based on this setting). You can change the setting (see propeller documentation) to achieve a better rate of climb or a better cruising speed. Always be careful when making this change and make a record of the current settings. When the propeller is set to achieve a maximum cruise speed, the takeoff distance is significantly longer. On the other hand, when the propeller is set to achieve good rate of climb, the fuel consumption during a level flight is higher. The finer pitch is being set (e.g. climb setting), the higher static RPM are achieved when aircraft is static and full power is applied.

## 4.1 TakeOff and Landing distances

Surface	Take Off Distance (m)	
	Ground run	Takeoff distance to 50 ft
Grass runway	150	320
Concrete runway	140	310

Surface	Landing Distance (m)	
	Landing distance from 50 ft	Ground run
Grass runway	350	170
Concrete runway	330	150

Both takeoff and landing distances are significantly increased by the following factors:

- Tail wind
- High airport altitude
- High air temperature
- Up-hill runway slope
- Runway wet or covered with snow, dust or water
- Propeller set to achieve better cruising performance

## 4.2 Rate of climb

	MTOW 560 kg
Rate of climb (fpm)	816 (4 m/s)

## 4.3 Cruise speeds

Maximum cruising speed at 75% ..... 172 km/h (Indicated)  
 (164 km/h Calibrated)

#### **4.4 RPM**

Max. take off power..... 5,800  
Max. continuous power ..... 5,500  
Cruise flight..... 4,200 – 5,200  
Idle speed .....approx. 1,600

#### **4.5 Fuel consumption**

<b>Engine settings</b>	<b>Fuel consumption (Litres / hour)</b>
Takeoff power performance	27
Max. continuous performance	23
Cruise performance	12 – 20

Fuel consumption during cruise flight is dependent on various factors. The most important ones are engine settings and propeller settings. The higher the engine RPM is set during cruise, the higher the fuel consumption. When propeller is set to minimum angle to achieve good climbing performance, level flight will be slower together with higher fuel consumption. When planning a flight, always consider all these and other factors like wind direction and speed or expected weather en route. Always plan for sufficient fuel reserve when arriving to the destination. Always carefully evaluate fuel consumption during the flight.

#### **4.6 Other performance data**

Max. endurance ..... 5,5 hours  
Max. range..... 962 km (519 NM)





after touchdown:

- brakes AS REQUIRED

### 5.2.3 In-flight Engine Failure

- airspeed 120 km/h

- landing site selection SELECT

- transmit MAYDAY on 121,5, ELT ON, XPDR 7700 - if time permits

check - master switch ON

- ignition ON

- backup battery switch ON

- main fuel valve OPEN

- wing tank fuel valves OPEN to tank with more fuel

- throttle SET TO 1/3 OF TRAVEL

- starter START THE ENGINE

If the engine cannot be started, proceed in accordance with procedure [5.2.25-2-2](#).

### 5.2.4 Additional information to engine failure and emergency landing procedures

If the engine failure occurs during the takeoff run, the pilots main concern should be to stop the aircraft on the remaining runway. Those extra items in the checklist are to add protection should the runway be too short to stop.

In flight, prompt reduction of pitch attitude to obtain and maintain a proper glide speed upon experiencing an engine failure is the first priority. If the failure has occurred shortly after takeoff, a landing should be planned straight ahead with only small changes in the flight direction to avoid obstacles. The best gliding ratio can be achieved with flaps up – flaps down will reduce the stall speed but at the same time deteriorating gliding performance. Try to stop rotation of propeller if restarting efforts are not successful – wind milling propeller has higher drag than stopped propeller.

While gliding towards a selected forced landing site, an effort should be made to determine and correct the cause of engine failure – time and altitude permitting. Do not concentrate on cause determination or restart effort unless you have selected a suitable landing site and you are confident of this manoeuvre. Flying the aircraft (especially maintaining the

proper gliding speed) is always the first priority. If the cause cannot be determined and corrected, the emergency landing must be accomplished.

Always announce your intentions and position after engine failure using radio and other equipment when time permits. Turn radio to international emergency frequency – 121.5 and transmit MAYDAY message. Activate Emergency locator transmitter (ELBA) if existing – set the switch to ON position. Set transponder (XPDR) to emergency code 7700. When the above mentioned procedure cannot be performed due to time constraints try to complete as many steps as possible. Transmitting MAYDAY message on the frequency already tuned on your radio should be the minimum procedure.

**WARNING**

**During a landing it is vital for the pilot to continue to fly the aircraft. Damages and/or injuries can be minimized if the pilot is fully concentrating on controlling the aircraft until it comes to complete stop**

### 5.3 In-flight Engine Starting

- airspeed 120 km/h
- landing site selection SELECT
- master switch ON
- backup battery switch ON
- main fuel valve OPEN
- wing tank fuel valves OPEN to tank with more fuel
- throttle ADJUST to 1/3 of travel
- ignition ON
- Backup battery switch ON
- starter key START UP
- if the engine cannot be started up, increase the airspeed to 136 – 160 km/h so that air flow can rotate the propeller, thus enabling engine starting.

**WARNING**

Loss of height needed for in-flight engine starting is about 500 to 650 ft.

### 5.4 Fire

Follow these procedure when fire or smoke in the engine compartment or cockpit is detected even though fires are extremely rare in properly maintained aircraft.

#### 5.4.1 Engine fire on the ground

- main fuel valve SHUT
- tank fuel valves SHUT
- throttle FULL
- ignition switch off when engine has stopped
- master switch OFF
- Fuel power switcher A/B OFF
- abandon the aircraft and extinguish fire (if possible)
- Fire damage INSPECT

<i>NOTE</i>	Time needed time to burn fuel remaining in engine fuel system after fuel valves are closed is around 30 sec.
-------------	--

<b>WARNING</b>	<b>DO NOT CONDUCT ANOTHER FLIGHT BEFORE THE FIRE CAUSE HAS BEEN DETERMINED AND REPAIRED BY AUTHORIZED PERSONNEL</b>
----------------	---

#### 5.4.2 Engine fire during takeoff

- throttle IDLE
- Fuel power switch A/B OFF
- main fuel valve SHUT
- tank fuel valves SHUT
- airspeed 120 km/h
- brakes STOP
- throttle FULL
- ignition switch off when engine has stopped.
  
- abandon the aircraft and extinguish fire (if possible) once the aircraft has stopped

### 5.4.3 Engine fire in flight

- |  |  |
|--|--|
| - main fuel valve  | SHUT   |
| - tank fuel valves                                       | SHUT   |
| - Fuel power switcher A/B                                | OFF  |
| - throttle   | FULL   |
| - airspeed   | INCREASE as required to find an airspeed which will provide as incombustible mixture. Do not exceed $V_{NE}$ |
| - landing site selection                                 | guide the aircraft to the nearest airfield, or choose a suitable landing site for emergency landing          |
| - ignition   | switch off when engine has stopped   |
| - master switch  | OFF  |
| - airspeed   | 120 km/h   |
| - wings flaps  | EXTEND AS NEEDED   |
| - safety belts   | TIGHTEN  |
| - perform emergency landing                              |  |
| - abandon the aircraft and extinguish fire (if possible) |  |

**WARNING**

**DO NOT ATTEMPT TO RESTART THE ENGINE**

**WARNING**

**DO NOT CONDUCT ANOTHER FLIGHT BEFORE THE FIRE CAUSE HAS BEEN DETERMINED AND REPAIRED BY AUTHORIZED PERSONNEL**

### 5.4.4 Cockpit or electrical fire

Electrical fires are usually signalled by the odour of burning insulation.

- |                               |                                       |
|-------------------------------|---------------------------------------|
| - cockpit door                | OPEN to remove smoke from the cockpit |
| - avionics and other switches | OFF                                   |

Land at the nearest suitable landing site. Consider shutting down the engine (and master switch) once the suitable landing site is reached. Extinguish fire as soon as possible.

## **5.5 Gliding**

gliding ratio .....	1 : 11
optimum gliding speed .....	110 km/h
rate of descent .....	551 fpm

Always consider flying through areas of descending air when calculating gliding range. Do not forget to have sufficient altitude to perform a landing procedure once suitable landing site has been reached.

## **5.6 Precautionary Landing**

- choose suitable landing site, evaluate wind direction and speed, surface, surrounding obstacles and total safety of the manoeuvre under consideration
- perform approach and fly-over at a speed of 120 km/h along the selected landing site at a height of 150 ft to estimate the area condition, obstacles and to determine exact landing direction
- Follow normal landings checklist and land

after touchdown

- |                 |             |
|-----------------|-------------|
| - Ignition      | OFF         |
| - master switch | OFF         |
| - fuel valves   | SHUT        |
| - brakes        | AS REQUIRED |

Precautionary landing should be preferred instead of emergency landing. When engine vibration or engine roughness is present, do not wait until the engine stops and perform a precautionary landing.

Precautionary landing is also used when a fuel exhaustion is imminent. This should not happen when a proper flight preparation is performed. Always perform a precautionary landing before all fuel is consumed, emergency landing following the loss of power is more complicated and more risky.

Also consider a precautionary landing when bad weather is encountered. Again, it should not happen when a proper flight planning is done. When the cloud base is forcing you to fly in low altitude and/or when visibility is limited, try to fly reverse or

other course to avoid bad weather area. If the conditions are not getting better or even are deteriorating, perform a precautionary landing before the conditions are getting even worse.

### **5.7 Blown-Out Tire Landing**

- carry out normal approach-to-land
- when flaring at landing, keep the damaged wheel above ground as long as possible using ailerons (or elevator for the nose wheel)
- maintain the direction at landing run, applying rudder

### **5.8 Damaged Landing Gear Landing**

- carry out a normal approach-to-land
- if the nose wheel is damaged, perform a touch-down on main wheels and hold the aircraft nose wheel up as long as possible till the speed is lost.
- if the main landing gear is damaged, perform touch-down at the lowest speed possible and maintain direction at landing run, if possible

### **5.9 Vibrations or other engine problem**

If any forced vibrations appear in the aircraft, it is necessary:

- to set engine speed to such power rating where the vibrations are the lowest
- to land on the nearest airfield, or to perform a precautionary landing off-airfield
- if the vibrations are increasing, carry out an emergency landing off-airfield, following procedures given under [5.2.25-2.2](#)

If the oil pressure reduces during a flight, an engine failure is probable. Reduce the engine power and execute a nearest airfield or precautionary landing before the engine failure occurs.

### **5.10 Inadvertent icing encounter**

- throttle                                    INCREASE above normal cruise settings
- course                                      REVERSE or ALTER as required to avoid icing

<b>WARNING</b>	<b>EVASIVE ACTION SHOULD BE INITIATED IMMEDIATELY WHEN ICING CONDITIONS ARE ENCOUNTERED</b>
----------------	---



## **6. Normal procedures**

All air speed values in this chapter are presented in km/h Indicated Airspeed, as this value represents instrument reading better than the Calibrated air speed.

### **6.1 Pre-flight inspection**

Pre-flight inspection must be conducted before the first flight of the day. The pre-flight inspection is recommended prior to any flight or series of flights by one pilot at any given day. Prior to any flight at least fuel and oil quantity should be checked.

If the aircraft has been stored outdoor, the engine area and other points of entry should be checked for evidence of bird occupancy. All control surfaces and travel stops should be examined for wing damages. Wheel fairings are not recommended for muddy field operation due to possible mud accumulation inside the fairings. When operating from gravel fields pay special attention to propeller leading edges. Fuel caps should be monitored for any deterioration periodically to avoid fuel leakage in flight or water infiltration.

The aircraft general condition should be noted during a visual inspection of the aircraft. Inspect any signs of deterioration, distortion and any damages to fabric skin of the aircraft. In cold weather, all traces of ice, snow, and frost should be removed from the aircraft. Make sure that no ice, snow or debris are trapped between any movable control surfaces.


Make sure that all instruments are in good condition, no broken glass. Airspeed indicator should read zero, altimeter should be checked against ramp or field elevation.

Do not activate the electrical system when anyone is near the propeller to prevent injury that can possibility resulting from electrical system malfunction.

Pay special attention to the propeller area – make sure the ignition and master switches are OFF before touching the propeller. Avoid touching propeller when possible to prevent possible injury resulting from electrical system malfunction.




## 6.2 Daily Inspection



### 1. Cockpit

POH and other documentation	review and available to pilot
master switch	OFF
backup battery switch	OFF
Strat power switch	OFF
ignition	OFF
Fuel pump switch A	OFF
Fuel pump switch B	OFF
fuel valves	OPEN, fuel quantity check
instruments	INSPECT
safety belts	INSPECT
flaperon tie rods	INSPECT
control stick	INSPECT, freedom of movement

rudder pedals	INSPECT, freedom of movement
brakes	INSPECT
trim	freedom of movement, proper function
engine controls	INSPECT, freedom of movement
loose objects in cockpit	remove
cockpit windows	INSPECT
door	INSPECT, shut and locked
2. Main landing gear	
gear legs and attachment	INSPECT
wheels	INSPECT, tire pressure 1.0 bar
brakes	INSPECT
3. Wings	INSPECT – wing, struts, hinges, surface
4. Pitot tube	INSPECT
5. Flaperons	INSPECT –hinges, surface freedom of movement counterweights attachment.
6. Rear cockpit cover	INSPECT, secured
7. Fuselage	INSPECT
8. Stabilizer, elevator, hinges	INSPECT – surface, hinges, attachment of stabilizer struts freedom of movement of elevator and trim tab.
9. Fin, rudder, hinges	INSPECT surface, attachment, freedom of movement condition and attachment of balance tab.
10. Nose wheel	INSPECT, tire pressure – 1 bar
11. Propeller	INSPECT / blades, propeller hub, check of locking propeller nuts (when visible)
12. Engine	Remove the top engine cowling and INSPECT - engine mount



INSPECT - air intake and controls

INSPECT - electrical system, ignition, cable connections

INSPECT - fuel system, filter

INSPECT - exhaust system

INSPECT – coolant, quantity (0.4 inch above bottom) - (between MIN and MAX marks), leakages –(see picture 1)

INSPECT – oil, quantity (between MIN and MAX marks), leakages.

Oil Check procedure:

**NOTE:** Propeller shouldn't be turned in reverse of the normal direction of engine rotation.

- Remove bayonet cap from the oil tank, turn the propeller slowly by hand in direction of engine rotation several times to pump oil from the engine into the oil tank.
- It is essential to build up compression in the combustion chamber. Maintain the pressure for a few seconds to let the gas flow via the piston rings into the crankcase. The speed of rotation is not important but rather the continuous pressure and the amount of gas which is transferred into the crankcase.
- This process is finished when air is returning back to the oil tank and can be noticed by an audible gurgle from the open oil tank.
- Check oil level and add oil if necessary.

The oil level should be in the upper half (between the "50%" and the "max" mark) and should not fall below the "min." mark of the oil dipstick. Prior to long flights oil should be added so that the oil level reaches the "max." mark.

Avoid oil levels exceeding the "max" mark, since excess oil could be poured out through the venting system.

### 13. Fuel

- Quantity (between MIN and MAX, at least middle for longer flights)
- INSPECT - draining off water and dirt from the central tank. Fuel system must be sampled daily to assure lack of contamination. Inspect the type of fuel.

- Fuel caps secured, correct vent orientation – open end against air in flight.

**WARNING**

**DO NOT FLY THE AIRCRAFT IF YOU FIND ANY DAMAGES OR PROBLEMS DURING A PRE-FLIGHT INSPECTION. ALWAYS CONSULT AUTHORISED PERSONNEL FOR REPAIRS**

### **6.3 Engine starting**

Lack of oil pressure within 10 seconds after engine starting can lead to serious engine damage.

Make sure nobody and/or nothing is near the propeller when starting the engine.

#### **6.3.1 Use of External Power Supply**

The external power supply may be connected to battery contacts when necessary through the connector of power supply which is located below the co-pilot seat close to the door.

#### **6.3.2 Engine Starting**

- |                         |                                   |
|-------------------------|-----------------------------------|
| - pre-flight inspection | COMPLETED                         |
| - safety belts          | ADJUST AND SECURE                 |
| - rudder pedals         | FREEDOM OF MOVEMENT               |
| - brakes                | CHECK FUNCTION                    |
| - control stick         | FREEDOM OF MOVEMENT               |
| - trim                  | FREEDOM OF MOVEMENT               |
| - wing flaps            | FREEDOM OF MOVEMENT,<br>RETRACTED |
| - engine control        | FREEDOM OF MOVEMENT               |
| - instruments           | CHECK OF VALUES, SETTINGS         |
| - doors                 | CLOSED, LOCKED                    |

- master switch SWITCH ON
- main fuel valve OPEN
- wing tank fuel valve OPEN TO TANK WITH MORE FUEL
- fuel pump switcher Main ON
- fuel pump switcher Aux OFF
- throttle IDLE
- control stick PULLED (clamped between legs)
- brakes ON
- propeller area "CLEAR"
- ignition SWITCH ON
- starter power switch ON – and holding during Start UP
- starter key SWITCH ON (10 sec as maximum without interruption, followed by a cooling period of 2 minutes)
- Warning Lamps Check if **Warning Lamps** illuminate and **extinguish** after around 3 seconds.
- Throttle After starting the engine, adjust speed to smooth operation – IDLE
- starter power switch release to position OFF
- instruments CHECK OF INDICATIONS (oil pressure must rise within 10 seconds. Increase of engine speed is permitted only at steady oil pressure readings above 30 PSI).  
  
Fuel pressure has reached its fuel pressure of 3 bar (43.5 PSI).
- Throttle valve **Increase engine speed above 2500 RPM and hold for 5 seconds** (Generator B shifts to Generator A).

Attention	If after engine start a warning lamp flashes or lights up, perform a Lane and Ignition check. Both warning lamps must be deactivated, otherwise there is an error. If one of the lamps illuminate or flashes: abnormal operation.
-----------	---

- |                               |   |
|-------------------------------|---|
| - Fuel pumps switchers        | Set both pumps switchers ON                               |
| - avionics and other switches | SWITCH ON (transceiver, IC, turn-and slip indicator ..... |

The aircraft has a tendency to roll forward easily on paved surfaces like asphalt even when the engine is at idle. The tail wind is also a significant factor. Make sure that the aircraft is not moving once the engine is started. If the aircraft is rolling and cannot be stopped with brakes, turn the engine immediately off using ignition switch.

### 6.3.3 Warming up engine

- Start warming up period at approximately 2000 RPM for approximately 2 minutes.
- Continue at 2500 RPM, duration depending on ambient temperature, until oil temperature reaches 50°C.
- Check temperatures and pressure.

## 6.4 Taxiing

### 6.4.1 Prior to Taxiing

Be aware of the entire area around the aircraft to ensure that the aircraft will clear all obstruction and other aircraft. When first beginning to taxi, the brakes should be tested for proper operation as soon as the aircraft is put in motion. If braking action is unsatisfactory, the engine should be shut down immediately.

- |              |                        |
|--------------|------------------------|
| - brakes     | FUNCTIONAL CHECK       |
| - stop watch | SWITCH ON, record time |

### 6.4.2 Taxiing

- taxiing speed is 14 km/h maximum. Steering is performed by rudder pedals controlling the nose wheel.
- in crosswind hold ailerons „upwind“, using the control stick.
- In strong crosswind perform the taxiing with an assisting person holding the wing by its windward side.
- When taxiing on gravel surfaces use as low engine power as possible to prevent damage to the propeller leading edges.

## 6.5 Normal TakeOff

### 6.5.1 Prior to TakeOff

- |                    |  |
|--------------------|--|
| - Oil temperature  | Minimum 50°C   |
| - brakes           | BRAKES ON  |
| - RPM              | 3850 RPM   |
| - Ignition         | CHECK (Lane A, BOTH, Lane B, BOTH). Engine speed should not drop/decrease more than 250 RPM.   |
| - RPM              | 2000 RPM   |
| - Fuel pumps       | Deactivate Auxiliary fuel pump for 5 seconds.<br>Check fuel pressure then activate Auxiliary fuel pump.<br>Deactivate Main fuel pump for 5 seconds.<br>Check fuel pressure then activate Main fuel pump. |
| - trim             | NEUTRAL  |
| - wing flaps       | TAKE-OFF POSITION  |
| - master switch    | ON   |
| - ignition         | ON   |
| - main fuel valve  | OPEN   |
| - tank fuel valves | FUEL QUANTITY CHECK, OPEN TO BOTH OR TANK WITH MORE FUEL QUANTITY  |
| - instruments      | CHECK  |
| - doors            | CLOSED, LOCKED   |
| - safety belts     | FASTENED, TIGHTENED  |
| - controls         | FREEDOM OF MOVEMENT  |
| - runway           | not occupied by another aircraft   |

### 6.5.2 Take-Off

Continuously increasing engine power to maximum (max. 5800 RPM should not to be reached if the aircraft is not moving), bringing the aircraft into motion. At a speed above 75 KM/H rotate the aircraft by slight pulling. Do not climb before the airspeed of 100 KM/H is reached. Then make a transition to climb, get the aircraft to climbing at a speed of 110 KM/H.

Accelerate during initial climb to 117 KM/H unless the best angle of climb is required. Maintain the airspeed during best angle climb carefully, do not let the speed drop below 110 KM/H.

- throttle	FULL
- engine instruments	CHECK
- elevator control	ROTATE at 75 km/h by slight pulling
- initial climb speed	110 km/h
- engine instruments	CHECK
- wing flaps	slowly FLAPS UP ABOVE 150 FT
- trimming	TRIM

### WARNING

**Take Off is forbidden - if engine running is not smooth.  
- if runway is occupied.**

Perform a brief magneto check before the takeoff after positioning the aircraft clear of other aircraft. When a magneto problem is present, do not take off. Monitor power and engine RPM early during takeoff run – if the engine RPM are lower than usually (exact RPM value depends on propeller settings) or engine is not running smoothly abort the takeoff immediately.

If taking off the from gravel surface apply the power slowly to prevent propeller leading edges damages.

Always retract wing flaps slowly – sudden retracting of wing flaps might cause a loss of attitude.

Always judge, based on your experience, whether the available runway is sufficient for normal takeoff. Always make a realistic estimation and be ready to abort the takeoff before critical speed is reached.

## 6.6 Best angle of climb speed ( $V_x$ )

### 6.6.1 Climbing

- throttle	5500 RPM MAX
- airspeed	95 km/h
- engine instruments	CHECK



## **6.7 Best rate of climb speed ( $V_y$ )**

### 6.7.1 Climbing

- speed 5500 RPM MAX
- airspeed 104 km/h
- engine instruments CHECK

## **6.8 Cruise**

### 6.8.1 Cruise Flight

- bring the aircraft into horizontal flight
- speed 4000 – 5500 RPM
- airspeed 110 – 152 km/h as required
- engine instruments CHECK
- fuel tank valves SWITCH BETWEEN TANKS (open one side and close the other) regularly

During cruising flight an RPM up to 5500 can be used. Always monitor all engine parameters during cruise flight, especially when high engine settings is set. Higher RPM means higher speed, but fuel consumption is increased significantly at the same time. An RPM setting around 4500 is usually the best compromise between time and fuel consumption. A propeller setting is always an important factor. Monitor minimum fuel bulb indication condition by pushing control button when you expect minimum fuel quantity (4.1 Litter).

Monitor the atmospheric condition as well – do not enter turbulence area in a high speed. Be ready for a sudden weather change during your flight – stronger head wind can limit your ability to safely reach planned destination.

Select carefully the flight path – avoid flying over large urban areas, large forests or large water areas as well as over mountains. Landing possibilities are very limited in case of engine failure or other emergency over those areas. Always have some suitable landing area within a gliding range. When it is necessary to cross a large area not suitable for emergency landing, always climb to the appropriate altitude to reach suitable landing site once emergency occurs.

Always monitor the airspace around you to prevent a mid-air collision.

**WARNING**

**Do not forget to change the wing tank supplying the engine on regular basis to prevent fuel starvation.**

**A proper fuel supply to the engine is provided by a central connecting tank during changing the active fuel tank change.**

## 6.9 Approach

### 6.9.1 Descent

- |                      |                               |
|----------------------|-------------------------------|
| - throttle           | INCREASED IDLE OR AS REQUIRED |
| - engine instruments | CHECK                         |

<b>WARNING</b>	<b>During long approaches and when descending from a considerable height, it is not advisable to reduce the engine throttle control to idle. In such case the engine becomes overcooled and a loss of power might occur. When descending, apply increased idle so that engine instrument readings range within the limits for normal use.</b>
----------------	---

### 6.9.2 Downwind

- |                               |  |
|-------------------------------|--|
| - power                       | 4000 – 5000 RPM  |
| - airspeed                    | 120 – 145 KM/H   |
| - engine instruments          | CHECK  |
| - fuel                        | FUEL QUANTITY CHECK, SWITCH TO TANK WITH MORE FUEL               |
| - brakes                      | CHECK FUNCTION BY SHORT BRAKING (check proper system resistance) |
| - safety belts                | TIGHTEN  |
| - base leg and final leg area | CHECK OF FREE AIRSPACE   |
| - landing site                | SITUATION  |

## 6.10 Normal landing

### 6.10.1 On Base Leg

- |                      |          |
|----------------------|----------|
| - power              | 3000 RPM |
| - airspeed           | 120 km/h |
| - engine instruments | CHECK    |
| - wing flaps         | TAKE-OFF |
| - trimming           | TRIM     |

- final leg airspace check of free space

### 6.10.2 On Final

- airspeed 120 km/h
- power ADJUST AS NEEDED
- engine instruments CHECK
- wing flaps LANDING
- trimming TRIM
- engine instruments WITHIN LIMITS
- check of clear landing site ( people, obstacles).

### 6.10.3 Landing

Always judge, based on your experience, whether the available runway is sufficient for normal landing. Always make a realistic estimation and be ready for aborting any landings.

At a height of about 30 ft reduce the engine speed to idle. Maintain speed of 120 km/h till flare. When flaring at a height of 1,5 to 3 ft above ground, decelerate gradually by pulling the control stick backward. At a speed of about 64 – 72 km/h the aircraft touches-down.

When landing with a significant crosswind component do not set the flap to landing position – use take-off setting to touch down at higher speed to ensure proper control over the aircraft before it touches the ground.

Entry speed to side slip ..... 120 km/h

### 6.10.4 After landing

- brakes APPLY WHEN NECESSARY
- wing flaps RETRACT
- trim TAIL HEAVY

### 6.10.5 Engine Stopping

- power cool down the engine at 2000 RPM when necessary
- engine instruments CHECK
- turn radio to 121,5 CHECK ELT IS NOT ACTIVATED.
- avionics and other switches OFF

- ignition OFF
- master switch OFF
- avionics and other switches OFF
- main fuel valve SHUT
- tank fuel valves SHUT
- secure the aircraft chocks or other way to prevent the aircraft from unintended movement, lock the controls (using safety belts)

During normal operation the engine is usually cooled enough during the approach and landing. Make sure that all avionics and other instruments are switched off before the engine is stopped.

Do not use parking brake to hold unattended aircraft, especially when the aircraft is located in hanger.

#### 6.10.6 Post-Flight Check

- check
  - damage of fuel system, fuel leakage
  - damage of oil system, oil leakage
  - damage of cooling circuit, liquid leakage
  - damage of electrical system, ignition
- check of aircraft exterior for damage
  - fuselage
  - wings, flaperons
  - tail unit
  - landing gear
  - fiberglass covers
- wash down the aircraft, clean it of dirt
- cover the cockpit with a protective cover

#### 6.11 Short field takeoff and landing procedures

The standard takeoff procedure should be followed. The only difference is that the full throttle is applied with brakes on – do not forget to have elevator in fully pull position to prevent aircraft turn over. Brakes are released when the maximum RPM are achieved by the engine. To clear possible obstacles in the runway direction climb at speed for best rate of climb – see section [6.76-6](#)

When approaching a short field make sure that the approach speed of 120 km/h is carefully maintained and full flaps are set.

## **6.12 Balked landing procedures**

- |                      |                               |
|----------------------|-------------------------------|
| - power              | MAX. 5500 R.P.M               |
| - airspeed           | 120 km/h                      |
| - engine instruments | CHECK                         |
| - wing flaps         | TAKE-OFF                      |
| - trimming           | TRIM                          |
| - wing flaps         | RETRACT AT A HEIGHT OF 150 FT |
| - trimming           | TRIM                          |
| - power              | MAX. 5500 RPM                 |
| - climb              | 120 km/h                      |

## **6.13 Information on stalls, spins and any other useful pilot information**

### **WARNING**

**Aerobatics, intentional stalls and spins are prohibited.**

### **6.13.1 Rain**

When flying in the rain, no additional steps are required. Aircraft qualities and performance are not substantially changed.

## 6.14 Towing Gliders

This Chapter contains information for towing gliders and complements each chapter precise specification which is important for maintaining flight performances of this airplane:

### 6.14.1 General

This EuroFox aircraft 3K is capable of towing gliders.

<b>Caution</b>	Lever for rope drop is painted in orange colour and it is located at the Center of instrument panel below throttle.
----------------	---

### 6.14.2 Flight limit

Towing gliders is permitted according data in this table:

- Maximal Take Off weight of glider.....	750 kg
- Maximal Take Off weight of towing aircraft .....	450 kg
- Towing rope has to include Reserve insert:	
- Maximal Breaking load for Reserve insert ...	<b>3000 N (300 kg)</b>
- Aero tow cable length .....	40 m - 60 m

### 6.14.3 NORMAL PROCEDURES for towing gliders

#### 6.14.4 Before Take Off

- Brake	set a brake
- Fuel pumps	Both On
- RPM	3500
- Trim	free running and functional check
- Wing flaps	to wind speed 5m/s – position I. about wind speed 5m/s - position 0.
- Master switch	On
- Ignition	On
- Main fuel valve	On

- |                            |   |
|----------------------------|---|
| - Wing tank fuel valves    | FUEL QUANTITY CHECK, OPEN TO BOTH OR TANK WITH MORE FUEL QUANTITY |
| - Instruments              | CHECK   |
| - doors                    | shut, locked  |
| - Safety Belt              | Fasten, Tightened   |
| - Controls                 | FREE OF MOVEMENT  |
| - check runway             | clean, another traffic  |
| - check of the towing rope | Connecting a rope and check in the mirror                         |

#### 6.14.5 Take OFF roll:

- |                      |   |
|----------------------|---|
| - take off roll      | maintain 80 - 96 km/h   |
| - speed              | max. cont. power, max. 5700 rpm.<br>setting optimal pitch propeller |
| - airspeed           | depends of type of gliders 100 – 140 km/h                           |
| - engine instruments | within limits   |

#### Caution

During Take Off rolling and climbing check attitude of glider in back mirror.

#### 6.14.6 Climbing:

- Maintain speed in range 110 – 140 km/h it depends of type of glider
- After Take Off flaps position – 0.
- Check RPM and maintain in range 5500 – 5750 rpm. Change throttle setting to optimal RPM.
- Check attitude of glider in the back mirror


#### Warning

Maintain airspeed during climb in desiderative range



6.14.7 Cruising speed according to limitations of towed glider

6.14.8 Before landing pilot has to go on low pass to drop the rope on the designate place



## **7. Aircraft Ground Handling and Servicing**

### **7.1 Servicing fuel, oil, coolant**

#### **7.1.1 Servicing fuel**

1. Verify the main switch OFF position
2. Verify that the doors are closed
3. Remove fuel tank cap
4. Service with fuel of proper type until level rises to the filler openings (or any required level)
5. Replace fuel cap and check for security
6. wash any spilled fuel from wings with a clean water
7. repeat for opposite fuel tank.

It is not advisable to change the used type of gasoline during engine operation. Refuelling should be carried out in places not endangering either the aircraft, its attendance or environment. Prior to refuelling it is always necessary to check gasoline for absence of water. Sampling should be done both from the transportation containers and from tanks and aircraft fuel system through drain sump. When refuelling from a barrel, a funnel must be used provided with a strainer to trap impurities, or, even better, with a buckskin leather which can trap also eventual fuel moisture content. Fuel dumping is performed similarly as sampling by means of a drain cock.

When filling fuel into tanks, be careful to avoid staining of cockpit window panels and glass with fuel as it contains corrosive components that will cause a fast deterioration and damage to cockpit glazing. Make sure that fuel tanks are closed when refuelling is finished.

#### **7.1.2 Servicing oil**

The proper oil type should be used – see this manual or engine manual.

1. Make sure that ignition and master switch are off
2. Remove the top engine cowling.
3. Open the oil tank.
4. When a level is not between minimum and maximum marks (or not high enough for expected longer operation), add oil. Do not add oil above the MAX level – the oil will be overflowed out of the engine anyway.
5. replace oil tank cap

6. replace the top engine cowling

The oil is to be changed every 50 or 100 hours of operation – see Maintenance manual and engine documentation for details. The first oil change is to be performed after initial 25 hours of operation of a new or overhauled engine.

### **7.1.3 Servicing coolant**

The proper coolant type should be filled in – see this manual or engine manual.

1. Make sure that ignition and master switch are off
2. Remove the top engine cowling.
3. Remove the cap of the coolant tank
4. Add estimated quantity of coolant
5. replace coolant tank cap
6. replace the top engine cowling

## **7.2 Landing gear tire dimension and pressure**

Track.....	1.96 m
Wheel base.....	1.3 m
Main landing gear wheel tire .....	8-8.00-6
Tire pressure.....	1.0 bar
Nose wheel tire .....	15-6.00-6
Tire pressure.....	1.0 bar

## **7.3 Towing and tie-down instructions**

### **7.3.1 Aircraft towing instruction**

1. Make sure that parking brake is off
2. Check the space around the aircraft and in the proposed direction of movement
3. Push and hold the tail down - use handle located on fuselage close to rudder leading edge
4. Push the aircraft in desired direction

Aircraft can be also towed using a tow bar – optional equipment, ask your dealer for details.

**CAUTION**

Never push, pull, or lift the aircraft by use of control surfaces

**7.3.2 Aircraft tie-down instruction**

1. Turn the aircraft into wind, if possible
2. Lock the controls (using safety belts)
3. Make sure that parking brake is on, install wheel chocks when possible.
4. Attach ropes to the ring located on the lower wing surface (front strut attachment)
5. Attach rope the nose wheel
6. Attach rope to the tail (between tail skid and fuselage)
7. Secure all ropes to the tie-down points

It is recommended to install a soft foam rubber or fabric cover into engine intakes to prevent debris accumulating inside the engine cowling. Before using chock make sure they do not collide with wheel fairings preventing any damage.

**CAUTION**

Never push, pull, or lift the aircraft by use of control surfaces

## 8. Required Placards and Markings

### 8.1 Airspeed indicator range markings

Marking	km/h IAS	Signification
White arc	60 ÷ 150	Range of wing-flaps use.
Green arc	70 ÷ 175	Normal range of operation.
Yellow arc	175 ÷ 205	Manoeuvres must be conducted with special caution and in smooth air
Red line	230	Never exceed speed

Overview of speed limits:

Speed		km/h IAS	Remarks
V <sub>NE</sub>	Never exceed speed	230	Do not exceed this speed in any operation.
V <sub>NO</sub>	Normal operating limit speed	175	This speed may be exceeded under smooth air only, do not apply deflections of control surfaces over one third.
V <sub>A</sub>	Manoeuvring speed	175	Do not apply full or steep deflections of control surfaces above this speed. The aircraft might be overloaded!
V <sub>FE</sub>	Maximum wing-flaps extended speed	150	Do not exceed this speed with wing flaps extended.
V <sub>S0</sub>	Minimum steady flight speed	60	with extended wing flaps
V <sub>S1</sub>	Minimum steady flight speed	70	wing flaps retracted

## 8.2 Operating limitation on instrument panel

**Manufacturer: AEROPRO s.r.o., 949 07 Nitra, Slovakia**

<b>Max. take-off weight:</b>		<b>560 kg</b>	
<b>Empty weight:</b>		<b>293,4 kg</b>	
<b>Never exceed speed</b>	<b>V<sub>NE</sub></b>	<b>230</b>	<b>km/h</b>
<b>Max. Flap Extended speed</b>	<b>V<sub>FE</sub></b>	<b>150</b>	<b>km/h</b>
<b>Stalling speed</b>			
<b>– wing level, flaps down</b>	<b>V<sub>S0</sub></b>	<b>60</b>	<b>km/h</b>

### 8.3 Passenger warning

This aircraft was manufactured in accordance with Light Sport Aircraft airworthiness standards and does not conform to standard category airworthiness requirements.

### 8.4 “No intentional spins”

The following placard is located on the instrument panel

**AEROBATICS, INTENTIONAL STALLS  
AND SPINS ARE PROHIBITED**

### 8.5 Miscellaneous placards and markings

Reserved

Passenger warning

**This aircraft was manufactured in accordance with Light Sport Aircraft airworthiness standards and does not conform to standard category airworthiness requirements.**

**Fuel tank capacity: 40 Litter  
Fuel specification:  
ASTM D4814 or AVGAS 100LL**

## 9. Supplementary information

### 9.1 Familiarization flight procedures

Familiarization flights procedure depends on pilot's experience. The whole familiarization should start with careful study of this document (Pilot Operating Handbook and Flight training supplement). Maintenance manual should be read as well.

The recommended procedure for experienced pilot usually consists of:

- Local flight in duration of approximately 30 minutes with instructor
- 5 to 10 traffic patterns with instructor
- 5 flights – emergency situations
- local flight do 30 minutes – solo
- 5 traffic patterns solo

Always perform as many flights as required to be able to properly control the aircraft, the syllabus above is for reference only.

### 9.2 Pilot operating advisories

reserved

### 9.3 Further Information

The following general information is recommended for further study among other books available:

The ***Pilot's Handbook of Aeronautical Knowledge*** provides general basic knowledge that is essential for pilots.

The ***Airplane Flying Handbook*** is designed as a general technical manual to introduce basic pilot skills and knowledge that are essential for piloting airplanes.